

1/11

DATA RECEPTION APPARATUS


RTP RECEPTION SECTION
RTCP TRANSMISSION SECTION

FIG. 1

2/11

DATA RECEPTION APPARATUS


 RTP RECEPTION SECTION
 RTCP TRANSMISSION SECTION


FIG. 2

3/11




FIG. 3

4/11




FIG. 4

5/11




FIG. 5

6/11




FIG. 6

7/11

DATA RECEPTION APPARATUS




FIG. 7

8/11




FIG. 8

9/11

RTSP REQUEST FROM DATA RECEPTION
APPARATUS TO SERVER

SET_PARAMETER rtsp://server/example.mp4 RTSP/1.0
CSeq: 3
Session: 57751252
trr-max-int=5000

FIG. 9

RTSP RESPONSE FROM SERVER TO DATA
RECEPTION APPARATUS

RTSP/1.0 200 OK
CSeq: 3
Session: 57751252

FIG. 10

10/11




FIG. 11




FIG. 12